

How to upgrade my drive?

This manual shows you how to upgrade your drive with the Philips DVD ReWriter Upgrade tool.



Philips Consumer Electronics
Version 04

PHILIPS

1 Start the Upgrade Tool you downloaded.
Click "OK"

2 Choose the drive to upgrade and click "Upgrade".

3 Click "OK" to confirm.

4 Your drive is being upgraded.
Do not interact with the system.

5 Your drive is now upgraded.
Click "OK" to exit the upgrade program.
Your system will be restarted.