Notice

The company reserves the right to make any updating, revisions or changes to the information contained herein as and when deemed necessary. The company is under no obligation to notify any purchaser or end-user of such actions in advance or afterwards.

2000

Trademarks

IBM PC, OS/2, PS/2, EGA, and VGA are registered trademarks of International Business Machines Corporation.

Intel, Pentium are trademarks of Intel Corporation.

MS-DOS, Microsoft Windows, Windows NT and Microsoft Mouse are registered trademarks of Microsoft Corporation.

Sound Blaster Pro is a trademark of Creative Labs, Inc.

SystemSoft is a registered trademark of SystemSoft Corp.

Other brand and product names are trademarks of their respective companies.

Safety Notice

The following mentions the incorrect handling that is seriously inhibited. To keep the computer from being damaged, please keep these precautions in your mind.

Do not turn off power in operation.

Do not place the computer on unstable surface.



Do not turn off the periphera device when the light is on.



Do not touch the poisonous liquid when the LCD panel is broken.



Do not touch the battery's contact plate with hands or metal objects.



Do not put the computer on surfaces that can block the ventilation.



Do not disassemble the computer yourself.



Do not place anything heavy on the computer.



Do not touch power cord by wet hand.



Do not use broken power cord.



Keep the computer or accessories away from any metal appliance.



Do not throw the computer or accessories into fire.



The following mentions the actions that are important for your computer. To keep your computer in the most excellent condition, please follow the instruction as much as possible.

If there is unusual odor, heat or smoke, plug out the power cord.



Plug out the power cord in attaching peripheral devices.



Follow the use instruction in taking airplane.



Use the same brand of peripheral devices.



Maintain your computer regularly.

Do not place heavy thing on the power cord.



Affix tape to the contact plate while putting the battery into keeping



Take a rest after a long term of work.

The data is easy to lose in low power status.



Please keep the computer away from humid environment.

Developing Good Work Habits

Developing good work habits are important if you need to work in front of the computer for long periods of time. Improper work habits can result in discomfort or serious injury from repetitive strain to your hands, wrists or other joints. The following are some tips to reduce the strain:

- Adjust the height of the chair and/or desk so that the keyboard is at or slightly below the level of your elbow. Keep your forearms, wrists, and hands in a relaxed position.
- Your knees should be slightly higher than your hips. Place your feet flat on the floor or on a footrest if necessary.
- Use a chair with a back and adjust it to support your lower back comfortably.
- Sit straight so that your knees, hips and elbows form approximately 90 degree angles when you are working.

In addition, continuous concentration on computing work can result in discomfort and injury. Remember to:

- Alter your posture frequently.
- Stretch and exercise your body several times a day.
- Take periodic breaks when you work at the computer for long periods of time. Frequent and short breaks are of greater benefit than fewer and longer breaks.

Lighting

Proper lighting and comfortable display viewing angle can reduce eye strain and muscle fatigue in your neck and shoulders.

- Position the display to avoid glare or reflections from overhead lighting or outside sources of light.
- Keep the display screen clean and set the brightness and contrast to levels that allow you to see the screen clearly.
- Position the display directly in front of you at a comfortable viewing distance.
- Adjust the display viewing angle to find the best position.

Table of Contents

Chapter 1: Getting Started 1-1
Checking the Items 1-2
Operating Environment 1-3
Providing Power 1-4
By AC Power Adapter 1-4
By Battery Pack 1-5
Opening the LCD Cover 1-6
Front View 1-7
LCD Panel 1-7
Microphone 1-7
Trackpad and Buttons 1-7
Stereo Speakers 1-7
Keyboard 1-7
Ventilation 1-7
Power Button 1-9
System Status Indicators 1-10
Rear Viiew 1-11
External Monitor (CRT) Port 1-11
Serial Port 1-11
Power Jack 1-11
Parallel Port 1-11
S-Video Jack 1-11
Expansion Port 1-12
Dual USB Ports 1-12
1394 Port 1-12
PS/2 Type Port 1-12
Left-Side View 1-13
Removable 3.5” Floppy Disk Drive 1-13
PC Card Sockets 1-13
Ventilation 1-13
Security Connector 1-13
Phone Jack (option) 1-15
Right-Side View 1-15

Speaker-out Jack 1-15
Microphone-in Jack 1-15
Removable 5.25” CD-ROM Drive 1-15
Line-in Jack 1-15
Infrared 1-15
Bottom View 1-17
CPU Cover 1-17
Hard Disk Drive 1-17
CD-ROM Drive 1-17
Battery Pack 1-17
Floppy Disk Drive 1-17
PC Card Sockets 1-17
Cover 1-17
Chapter 2: Operation 2-1
Upgrading the Processor Module 2-2
Replacing the Processor 2-2
Reinstalling the Heat Sink 2-3
Expanding the Memory 2-4
Accessing the Memory Sockets 2-5
Installing the Memory Module 2-6
Removing the Memory Module 2-7
Using the Hard Disk Drive 2-8
Removing the Hard Disk Drive Module 2-8
Replacing the Hard Disk Drive 2-9
Inserting the Hard Disk Drive Module 2-9
Using the Floppy Disk Drive 2-10
Inserting/Removing Diskettes 2-10
Removing/Inserting the Floppy Disk Drive 2-11
Using the CD-ROM 2-12
Removing the CD-ROM Module 2-13
Inserting the CD-ROM Module 2-13
Loading Compact Discs 2-14
Handling Compact Discs 2-15
Using the PC Card Sockets 2-16
Inserting PC Cards 2-16
Removing PC Cards 2-17

Using the Hot Keys 2-18
Using the Numeric Keypad 2-20
Using the Power Management 2-21
Advanced Power Management (APM 1.2) 2-21
Global Standby 2-21
Hard Disk Standby 2-21
Suspend and Resume 2-22
Attaching Peripheral Devices 2-24
Attaching a Phone Line (option) 2-24
Attaching a Parallel Printer 2-25
Attaching a TV Set 2-26
Attaching a USB-compatible Device 2-27
Attaching a Serial Mouse 2-28
Attaching an External Monitor (CRT) 2-29
Attaching a PS/2 Keyboard or Mouse 2-30
Chapter 3: BIOS Utilities 3-1
Power on Self Test (POST) 3-2
Post Message: Normal Operation 3-2
POST Message: Error Detected 3-3
System Configuration Utility 3-4
Information in the System Configuration Utility 3-4
Initiating the System Configuration Utility 3-5
Working with the Menu Bar 3-6
Working with the Pull-down Menu (Submenu) 3-7
Features of the SCU 3-8
Startup Menu 3-8
Memory Menu 3-10
Disks Menu 3-11
Components Menu 3-12
Power Menu 3-15
Exit Menu 3-18
Chapter 4: Troubleshooting 4-1
Audio 4-2
Battery 4-2
Boot Password 4-4
CD 4-4

Floppy Disk Drive (FDD) 4-5
Hard Disk Drive (HDD) 4-5
Hardware Installation 4-6
LCD Panel 4-6
Memory Module 4-7
PC Card 4-8
Power 4-8
Printer 4-9
Chapter 5: Installing Drivers 5-1
Installing Windows 95 5-2
Installing Windows 98 5-4
Installing Drivers in Windows 95 5-5
Step 1: Running USB supplement path 5-5
Step 2: Installing TXPATCH Driver 5-5
Step 3: Installing VGA Driver 5-5
Step 4: Installing Audio Driver 5-6
Step 5: Installing Mediamatic DVD Play Driver (Option) 5-7
Step 6: Using Infrared Wireless Communication 5-7
Installing Drivers in Windows 98 5-8
Step 1: Installing VGA Driver 5-8
Step 2: Installing Audio Driver 5-9
Step 3: Installing PCMCIA Driver 5-9
Step 4: Installing ATI DVD Play Driver (Option) 5-10
Installing Drivers in Windows NT4.0 5-11
Step 1: Installing VGA Driver 5-11
Step 2: Installing Audio Driver 5-12
Appendixs 1
A. Specifications 1
B. I/O Port Pin Assignments 5
C. Jumper Setting 10